

# THE LEAF MAN

## GUTTER GUARD



**NO TRIMS,  
NO SADDLES,  
FASTER  
INSTALLATION**

# Installation Guide



**SCAN TO VIEW  
INSTALLATION VIDEO.**



# Installation Procedure for **TILE ROOF**



## Step 1 Cleaning the Gutters

It is important that all leaves and debris are removed from gutters, valleys and to flush all connecting downpipes thoroughly prior installation.



## Step 2 Exposing the guttering

Slide back the first row of tiles away from the gutter.



## Step 3 Attaching Guard to the Gutter

Place guard to step down into the roof with the top edge sitting on top of the gutter lip. Screw in every 300mm.



## Step 4 Joining the Pieces

Continue along the gutter lip overlapping every 100mm.



## Step 5 Corners

Using the snips, cut guard to shape, overlap and screw to gutter lip accordingly



## Step 6 Finishing

Slide the tiles back into place over the bottom of gutter guard which will fit snug against the guard fold.

# Installation Procedure for CUSTOM ORB



## Step 1 Cleaning the Gutters

It is important that all leaves and debris are removed from gutters, valleys and to flush all connecting downpipes thoroughly prior installation.



## Step 2 Lining up the Profile

Firstly, place guard to the lip of the gutter matching the Custom Orb profiles.

The Custom Orb cut out of the guard with sit in-between each orb to fit like a jigsaw puzzle.



## Step 3 Attaching Guard to the Gutter

Screw the guard into the lip of the gutter every 300mm.

Screw the guard into every second orb underneath first row and in line with the roof screws.



## Step 4 Joining the Pieces

We recommend a 10mm overlap.

This is simply to ensure there are no gaps.



## Step 5 Corners

Using the snips, cut guard to shape, overlap and screw to gutter lip accordingly.



## Step 6 Sealing the Product to Roof

Adding a thin bead of silicon is optional but recommended in heavily treed areas.

# Installation Procedure for METAL ROOF



## Step 1 Cleaning the Gutters

It is important that all leaves and debris are removed from gutters, valleys and to flush all connecting downpipes thoroughly prior installation.



## Step 2 Lining up the Profile

Line up the straight edge of gutter guard to lip of gutter.

A handy tip to ensure the perfect fit is to screw directly in the middle of the guard on the edge to the gutter lip as your starting point.



## Step 3 Attaching Guard to the Gutter

Screw guard into gutter edge (either side of middle screw) every 300mm or so and into every raised ridge of roof profile.



## Step 4 Joining the Pieces

We recommend a 10mm overlap.

This is simply to ensure there are no gaps.



## Step 4 Parapet Wall

For box gutters screw the folded edge of guard to wall as you would a gutter lip.



## Step 5 Corners

Using the snips, cut guard to shape, overlap and screw to gutter lip accordingly.

## Installation Procedure for STEALTH & TILE VALLEYS



### Step 1

Prior to installation, measure the width of the valley gutter for a custom fit and clean out before installing gutter guard.



### Step 2

**Stealth Valley:** Insert guard under each roof sheet.

**Tile Roof:** Slide the tile back and place guard down into the roof bracket. Slide tile back over guard so it sits underneath.



### Step 3

Screws pieces together.



### Step 4

For both Stealth valleys and a Tile roof, product will fit in snug, push down on top of guard to firmly secure into place.

## Installation Procedure for FLAT & CORRUGATED ROOF VALLEYS



### Step 1

Lay guard over valley and screws in either side (15 screws per each side per piece).

Use a mallet to band down guard edges into roof grooves.



### Step 2

Once guard is fitted firmly into place a bead of silicone is optional along edges to finish.

## Installation Procedure for DROP IN CORRUGATED ROOF



### Step 1

Clean out gutters.

Insert the pre folded back of gutter guard un roof sheets.



### Step 2

Simply press front edge of gutter guard into lip of the gutter.

Product will sit on top for internal brackets.

Product will sit in the back of gutter for external brackets.



### Step 3

Press guard down along edge to roof sheet where required.

No screws required.

## Installation Procedure for DROP IN TILED ROOF



### Step 1

Clean out gutters.

Insert the pre folded back of gutter guard up against edge of tile.



### Step 2

Simply press front edge of gutter guard into lip of the gutter.

Product will sit on top for internal brackets.

Product will sit in the back of gutter for external brackets.



### Step 3

Press guard down along edge to roof sheet where required.

No screws required.